



BLAKES BUILDING PROFILES LTD **REVERSE EXTERNAL PROFILE**

Used for building internal corners and for use with the Blockdolly

Quick and easy to set up

Clamping arms are set up to push into corner (opposite way to pulling out on an External corner)



Screw the M12 wing nut onto the clamping bolt (wings first) and engage the hooked end of the bolt into the hole in the profile side plate. Slide the clamp (long end first) onto the clamping bolt until the large end drops into the vertical joint. Tighten the wing nut against the clamp allowing the profile to be pushed into the corner. Repeat on the opposite side, tightening the wing nuts evenly to keep the profile square with the corner.